

# PUFAS Wallpaper Adhesive BW plus

## PUFAS Wandbelagskleber BW plus

- premium-quality adhesive for heavy wall coverings, textile, vinyl, textured, glass fibre and metal wallpapers
- very high bond strength
- ideal consistency for application
- very high moisture resistance when overcoating
- dries to transparent finish
- ideal for increasing bond

### Instructions for use:

For pasting textile wall coverings, woven fabric wallpapers, glass cloth, PVC foils with woven backings as well as for use as a wallpaper adhesive additive

### Technical specifications:

Components: Polyvinyl acetate ethylene emulsion  
 pH-value: approx. 9,5-10,5  
 Density: approx. 1.02 g/cm<sup>3</sup>  
 Usage: 200-300 g/m<sup>2</sup>

### Substrate preparation:

The surface must be dry, firm, dust and free of release agents (dust, grease, etc.) Remove all old, loose wallpapers and distempers using PUFAS Wallpaper Remover TL. Make good cracks and holes using Interior Filler FSI or PUFAMUR Super Bonding Filler SH45. Pre-treat highly absorbent, sanding and chalking surfaces with PUFAS Hydrosol Primer Deep-Penetrating LF.

### Application:

As a wall covering adhesive: Evenly apply PUFAS Wallpaper Adhesive BW plus to the surface over a width equal to the width of the wall covering using a roller or brush and place the wall covering, cut to size, in the moist adhesive bed. If the adhesive is to be applied directly to the wall covering, observe the prescribed softening time. Always observe the wall covering manufacturer's pasting guidelines!

As a border adhesive: Moisten the borders with water and then apply a thin, uniform coat of PUFAS Wallpaper Adhesive BW plus to the border. Fold the pasted ends of the borders together, roll up and leave to soften. After the prescribed softening time place the border on the surface and uniformly press into place.

Observe the border manufacturer's instructions for use!

As an additive for wallpaper adhesive: PUFAS Wallpaper Adhesive BW plus can be used to increase the adhesive strength and moisture resistance of wallpaper adhesives. Thoroughly stir PUFAS Wallpaper Adhesive BW plus into the already dissolved wallpaper adhesive. The optimum amount to be added is approx. 15-20 % e.g. a 750-g tin of PUFAS Wallpaper Adhesive BW plus to 4 l stirred wallpaper adhesive.

### Note:

Please see EU safety data sheet for all safety-related data (EU-CLP)

Do not use if the surface and/or room temperature are below + 5° Celsius! Clean tools in water after use.

Immediately remove residual adhesive using a damp cloth.

### Considerations disposal:

Please see EU safety data sheet section 13 (EWC).

### Storage:

Store in a cool place! Keep containers tightly sealed! The adhesive is frost- resistant.

If frozen, defrost in room temperature and stir before use.

### Available sizes:

|       |               |           |     |
|-------|---------------|-----------|-----|
| 750 g | 4007954012017 | 001201000 | REG |
| 750 g | 4007954012918 | 001201092 | CIS |
| 3 kg  | 4007954012024 | 001202000 | REG |
| 5 kg  | 4007954012031 | 001203000 | REG |
| 10 kg | 4007954012048 | 001204000 | REG |
| 18 kg | 4007954012055 | 001205000 | REG |

### Note:

All details and data presented in this information sheet are based on our practical experience and laboratory investigations, and reflect the current state of the art. They can, however, only serve as general guidance and shall provide no guarantee of specific properties or performance. Given that the conditions for storage, transportation and application of products are beyond our control, no legal liability may be construed from the information presented here. It shall be the responsibility of the user to check the product's suitability for the envisaged purpose under the specific site or project conditions.